





- Panel lining can be used together with rails
  - Full lining cannot be combined with rails.
  - Joint strip can be used to keep 2 linings together.
  - Additional screws are recommended when installing roof and larger wall linings.
1. Take out existing linings and rails from the van.\*
  2. Clean all the surfaces in the van.
  3. Place the Modul-Linings in position and make sure everything fits.

\* Original lashings, rails, bulkhead, seats and other accessories that are removed from the van during installation of "Modul-Lining" shall be reinstalled according to OEM instructions.



6. Add spots of glue to the panels' flat side, only apply glue for one part at a time.
7. Start assembling from top and go downwards in the vehicle. The rough surface should face inwards.



**Drying time 24 h**



**GLUE LINING 290 ml**  
Item no 39237



**SAFETY GEAR FOR GLUE**

